

Hard Reset XIAOMI MIJIA ROBOROCK S55

How to hard reset XIAOMI MIJIA ROBOROCK S55

If normal operation of the **XIAOMI MIJIA ROBOROCK S55** is not restored, try to **Hard Reset XIAOMI MIJIA ROBOROCK S55**.

Attention! **Hard Reset** the system will destroy properties of scheduled cleanings and cleaning modes and also reboot the Wi-Fi connection.

First Method:

1. Open top cover to find **Reset Button** just beside the Wi-Fi indicator.
2. Press and hold the **Charge Button**.



3. Use a paper clip or a toothpick to click **Reset Settings Button** once. Don't stop holding **Charge Key**, it must be pressed all the time.



4. Keep Charge Button for another 5 seconds until you hear a voice message about "**Restoring the factory settings**" and **Power Button light** will start blinking.
5. Release Charge Key and give XIAOMI robot about five minutes to reboot if MIJIA ROBOROCK S55 will not restart itself place it manually on the **charging station**.
6. After that, **all settings will be reset**.